

IF THE AUXILIARY OUTPUT IS NOT UTILIZED, INDIVIDUALLY TAPE UP AND ISOLATE THE ORANGE & GREEN WIRES

IF THE AUXILIARY INPUT IS NOT UTILZED, TAPE UP AND ISOLATE THE WHITE WIRE

COOL BOOST WATER METHANOL SYSTEMS SNS STAGE 2 V3 PROGRESSIVE WIRING SCHEMATIC GENERIC

